

### 3-Pack Magnifier Set

Congratulations on selecting your new Carson magnifier set! In order to achieve optimum performance, please follow instructions for proper use and care.

#### USING THE HANDHELD MAGNIFIER

Place magnifier over the subject you are viewing.

**For Best Results:**

- Depending on your vision, you may need to move the magnifier closer or further away until focused.



#### USING THE SPOT LENS

To see superfine details, use the spot lens.

**For Best Results:**

- The magnifier should be close to the object when using the spot lens.

#### USING THE FLIP-OPEN MAGNIFIER

1. Slide magnifier from built-in case.
2. Place magnifier over the subject you are viewing.

**For Best Results:**

- Depending on your vision, you may need to move the magnifier closer or further away until focused.

3. When through, slide magnifier back into case to protect lens.




#### USING THE CREDIT CARD SIZE FRESNEL MAGNIFIER

1. Slide magnifier from case.
2. Place magnifier over the subject you are viewing.

**For Best Results:**

- Depending on your vision, you may need to move the magnifier closer or further away until focused.

3. When through, slide magnifier back into case to protect lens.



#### CARE

Clean using microfiber lens cloth. Do not use any abrasives, chemical cleaners, or solvents.

**Customer Service:** If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

[www.carson.com](http://www.carson.com)

Carson Optical 2070 5th Avenue,  
Ronkonkoma, NY 11779  
Tel: 631-963-5000

For warranty information, visit [www.carson.com/warranty](http://www.carson.com/warranty)